


Nilo® N80s Theasel™

Assembly Instructions

Please retain this information for future reference




WARNING:

ADULT ASSEMBLY REQUIRED.


Product includes small parts with potentially hazardous sharp points and sharp edges in the unassembled state. Keep unassembled parts away from children.



Step1




Step2




DO THIS STEP ON A FLAT SURFACE SO THE EASEL WILL NOT WOBBLE.


Step3




Step4




Step5




Step7



Step8



Step6



Step9

